


USE THE PROGRAM MOTORCONTROL.EXE, AVAILABLE AT WWW.ALLTRAXINC.COM
TO ADJUST THE MOTOR CONTROLLERS OPERATING PARAMETERS.

ADJUSTMENTS INCLUDE:
ACCELERATION RATE, UNDERVOLTAGE AND OVERVOLTAGE SHUTDOWN.



HIGH CURRENT WIRING SHOW IN BOLD

Title			
AXE PUMP MOTOR CONTROL WIRING			
Size	Document Number	Rev	
B	PUMP_WIRES_1	2	
Date:	Wednesday, November 10, 2004	Sheet	1 of 1